


# HK 4400 SWEEPER

Serial Number: 20A01 +  
Part # 301012



## *HARPER HAWK* *OPERATOR'S* *MANUAL*



## Thank you for purchasing a Harper Hawk.

As with all Harper products, the Harper Hawk has been developed through tough design and testing procedures to produce a top-quality machine. This manual gives assembly, operating, and service information for the model HK4400 Sweeper and was written in compliance with ISO 3600: 2015(E). Please read and understand all instructional material included with the Sweeper or its components before assembling and operating the equipment. For identification of replacement parts, see the Parts Manual.

A Sweeper can present hazards to an operator who follows unsafe procedures in either the operation or maintenance of the unit. Therefore, **SAFETY WARNINGS** are presented at certain locations in the text.

THIS SYMBOL:



**MEANING:** Failure to understand and obey this warning may result in injury or death to you or others. Whenever this symbol is used, please pay very close attention to the information presented, and make sure you fully understand. If you do not, contact your dealer or Harper Industries, Inc. for clarification.



**ALL SHIELDS AND GUARDS MUST BE IN PLACE FOR PROPER AND SAFE OPERATION OF THIS EQUIPMENT. WHERE THEY ARE SHOWN REMOVED IN THIS MANUAL, IT IS FOR PURPOSES OF ILLUSTRATION AND INSTRUCTION ONLY. DO NOT OPERATE THIS EQUIPMENT UNLESS ALL SHIELDS AND GUARDS ARE IN PLACE.**



**WARNING:** Breathing diesel engine exhaust exposes you to chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

- Always start and operate the engine in a well-ventilated area.
- If in an enclosed area, vent the exhaust to the outside.
- Do not modify or tamper with the exhaust system.
- Do not idle the engine except as necessary.

For more information go to [www.P65warnings.ca.gov/diesel](http://www.P65warnings.ca.gov/diesel)

Harper Industries, Inc. is continually striving to improve the design and performance of its products. We reserve the right to make changes in specifications and design without thereby incurring any obligation relative to previously manufactured products.

© 2021 Harper Industries, Inc.

The Harper name is a registered trademark of Harper Industries, Inc. All other brand and product names are trademarks or registered trademarks of their respective companies.

## LIMITED WARRANTY

Harper Industries, Inc. (HII) warrants to each purchaser of a new Harper Hawk from an authorized dealer or representative, that such equipment is free of manufacturer's defects in workmanship and materials which appear while in normal service for a period of ONE YEAR commencing with delivery to the original user.

The obligation of HII under this warranty is expressly limited, at our option, to replacement or repair at a service facility designated by Harper Industries or at the manufacturing plant in Harper, KS. A part will be replaced after inspection discloses it to have been defective. This warranty does not apply to defects caused by damage or unreasonable use (including failure to provide reasonable and necessary maintenance, or by performing functions without genuine Harper Hawk accessories) while in the possession of the consumer.

Warranty is limited to parts, labor and ground freight delivery of replacement parts. HII shall not be liable for the consequential damages of any kind, including but not limited to consequential labor costs or transportation charges in connection with replacement or repair of defective parts.

This warranty does not apply to parts subjected to misuse, abuse, alteration, improper or inadequate maintenance, or normal wear (including belts, battery, chains, filters, paddles, and brush).

Engines are not covered under this warranty. Refer to manufacturer's warranty for specific warranty information. Harper Industries, its agents or representatives, make or imply no other warranties.

Harper Industries makes no warranty with respect to trade accessories. They are subject to the warranties of their respective manufacturers.

ANY IMPLIED OR STATUTORY WARRANTIES, INCLUDING ANY WARRANTY OR MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, ARE EXPRESSLY LIMITED TO THE DURATION OF THIS WRITTEN WARRANTY. HII makes no other express warranty, nor is anyone authorized to make any on behalf of HII.

For further information please contact your nearest Harper Hawk dealer.

## RECORDS

Date of Purchase \_\_\_\_\_ / \_\_\_\_\_ / \_\_\_\_\_

Dealer's Name \_\_\_\_\_

Dealer's Phone \_\_\_\_\_

Serial Number Machine \_\_\_\_\_

Serial Number Engine \_\_\_\_\_

# Table of Contents

## OPERATOR SECTION

|                                       |    |
|---------------------------------------|----|
| To the Owner or Operator.....         | 1  |
| Warranty Statement.....               | 2  |
| Table of Contents.....                | 3  |
| Specifications.....                   | 4  |
| Identifications                       |    |
| Control Identification.....           | 5  |
| Machine Display Identification.....   | 7  |
| Deck Identification.....              | 8  |
| Hopper Identification.....            | 8  |
| Safety Guidelines                     |    |
| Equipment & Controls.....             | 9  |
| Safety Decals.....                    | 9  |
| Diesel Fuel.....                      | 9  |
| Guards & Shields.....                 | 10 |
| Battery.....                          | 10 |
| Hydraulics.....                       | 10 |
| Safety Interlocks/Wiring Logic.....   | 10 |
| Safety Symbols.....                   | 10 |
| Locations.....                        | 12 |
| Safety Locks.....                     | 13 |
| Operation                             |    |
| Before Operation.....                 | 14 |
| Operation.....                        | 15 |
| Operating Machine.....                | 16 |
| Sweeping Performance.....             | 17 |
| After Operation.....                  | 17 |
| Storage.....                          | 17 |
| Maintenance                           |    |
| Hydraulic System.....                 | 18 |
| Grease Zerk Locations.....            | 19 |
| Air Cleaner.....                      | 19 |
| Cooling System.....                   | 20 |
| Engine Compartment.....               | 20 |
| Engine Oil.....                       | 20 |
| Fuel Components.....                  | 21 |
| Fuse/Relay Panel.....                 | 21 |
| Deck Maintenance/Service.....         | 21 |
| Hopper Maintenance.....               | 24 |
| Tow Procedure                         |    |
| Park Brake Release.....               | 24 |
| Opening the By-Pass Valve.....        | 25 |
| Tie Down Locations for Transport..... | 26 |
| Serial Number IDs.....                | 26 |
| Standard Torque Chart.....            | 27 |
| Service Parts.....                    | 27 |
| Maintenance Schedule.....             | 28 |

## Specifications

|                                   |                                                                                                                                                                                                                                                                                                                                                            |
|-----------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Power</b>                      | Diesel - Kubota V1505-E4B 24.8 HP @ 2300 RPM                                                                                                                                                                                                                                                                                                               |
| <b>Configuration</b>              | Self-contained, 4-wheel configuration with front steering, four drive wheels, and a rear mounted, high-lift, debris hopper with patented recirculating air technology                                                                                                                                                                                      |
| <b>Sweeper</b>                    | 60 in (152 cm) wide x 12 in (30 cm) diameter sweeping rotor contained in a floating deck housing with rear mounted gauge wheels and front mounted anti-scalp wheels; rises to transport position and lowers to operating position by hydraulic cylinder; Polypropylene brush is standard                                                                   |
| <b>Paddle</b>                     | 18 in (45 cm) diameter with 4 removable paddles that is also contained inside the floating deck housing.                                                                                                                                                                                                                                                   |
| <b>Debris Hopper</b>              | Capacity – 3.36 cubic yards (2.57 cu m)                                                                                                                                                                                                                                                                                                                    |
| <b>Lift</b>                       | Rises 71" (180 cm) above the ground to dump debris into vehicle or container.                                                                                                                                                                                                                                                                              |
| <b>Drive</b>                      | Hydrostatic pump directly coupled to engine drives four Poclain high-efficiency piston drive hydraulic motors on all wheels with two speed operation, traction control and torque transfer capability; foot operated pedal for forward and reverse drive.                                                                                                  |
| <b>Speed</b>                      | Infinitely variable, 0-5 mph (0-8 km/h) low (operation), 0-10 mph (0-16 km/h) high (transport), 0-10 mph reverse; Dynamic braking through the hydrostatic drive system, mechanically applied and hydraulically released parking brake on all wheels.                                                                                                       |
| <b>Main Frame</b>                 | Welded and formed steel frame                                                                                                                                                                                                                                                                                                                              |
| <b>Tire and Wheels</b>            | Front: 24x9.5-12 Litefoot 4ply, Rear: 24x12-12 Litefoot 4ply                                                                                                                                                                                                                                                                                               |
| <b>Compaction</b>                 | Front: 10 psi (69 kPa), Rear: 9 psi (62kPa)                                                                                                                                                                                                                                                                                                                |
| <b>Steering</b>                   | Power steering with automotive type steering wheel, tilt steering                                                                                                                                                                                                                                                                                          |
| <b>Controls</b>                   | Hydraulic lift/lower of debris hopper<br>Hydraulic open/close of debris hopper door<br>Hydraulic raise/lower of sweeping mechanism head assembly<br>Hydraulic power of sweeper and paddle                                                                                                                                                                  |
| <b>Seat</b>                       | Adjustable ride suspension, high back, and retractable seat belt                                                                                                                                                                                                                                                                                           |
| <b>Electrical</b>                 | 12-volt, electronic key start                                                                                                                                                                                                                                                                                                                              |
| <b>Dimensions</b>                 | Length – 153 in (389 cm), Height – 79 in (201 cm), Width – 76.5 in (194 cm), Wheel Base – 80 in (203 cm)                                                                                                                                                                                                                                                   |
| <b>Weight</b>                     | 4480 lbs. (2,032 kg)                                                                                                                                                                                                                                                                                                                                       |
| <b>Liquid Capacities</b>          | Fuel – 12 gal (45 L); Hydraulic Fluid – 2 gal (7.6 L) Tank<br>Engine Oil – 1.59 gal (6.0 L); Coolant – 2.25 gal (8.5 L)                                                                                                                                                                                                                                    |
| <b>Safety &amp; Hydraulic Oil</b> | Includes Certified ROPS and seatbelt and Crown AW46; ISO 46 Hydraulic Oil                                                                                                                                                                                                                                                                                  |
| <b>Safety</b>                     | Certified ROPS: ISO 21299 ref Mass 2036 Kg<br>Seatbelt<br>Electrical Interlocks: <ul style="list-style-type: none"> <li>To start the machine: Must be in neutral &amp; deck rotor/paddle must be OFF.</li> <li>To turn deck rotor/paddle ON: Operator must be in the seat.</li> <li>Park brake is applied when the operator is out of the seat.</li> </ul> |
| <b>Hydraulic Oil</b>              | Crown AW46; ISO 46 Hydraulic Oil                                                                                                                                                                                                                                                                                                                           |
| <b>Optional Attachments</b>       | Canopy, Work Lights, and Beacon - See Part's Manual pages 11.1-11.3 for more details.                                                                                                                                                                                                                                                                      |

**NOTE:** Following publication of this manual, certain changes in standard equipment and/or options may have occurred which would not be included in these pages. Your Harper dealer is the best source for up-to-date information.

## Control Identification

**ROPS** – Roll-Over Protective Structure is certified and designed to protect operator in case of a roll-over. Always wear a safety belt.

**Steering Wheel** – steering is hydraulically controlled. Steering wheel angle may be adjusted with tilt lever.

**Control Panel** – all functions of the Harper Hawk may be controlled from the operator's seat.

**Foot Pedal** – hydrostatic pump is controlled by pushing foot pedal forward and backward.

**Lift Mechanism** – raises the bottom of the hopper to a height of 71" (180 cm) to dump into a vehicle or container.

**Use extreme caution when raising the hopper as the top can reach approx. 134 in (340 cm).**

**Deck Transition** – stationary shielding that surrounds the deck and provides a seal between the hopper and deck.

**Sweeper Deck** – contains rotating sweeping rotor and paddle that moves material from the ground to the hopper.

**Engine** – Diesel: Kubota V1505-E4B 24.8 HP

**Hopper** – stores up to 3.3 cubic yards (2.57 cu m) of material. Always empty hopper at end of operation.

**Hopper Door** – opens, closes and locks when the lever is activated by the operator.



**Radiator/Oil Cooler** – equipped with removable screen.

**Canopy (optional)** – attachment that bolts to the ROPS to provide shade for the operator; ABS plastic.



**Brush/Paddle ON/OFF** – turn deck on when engine is low to mid-throttle.

**Deck UP/DOWN** – deck is hydraulically raised and lowered using lever.

**Hopper UP/DOWN** – hopper is hydraulically raised and lowered using lever. Raise hopper with extreme caution.

**Door OPEN/CLOSE** – hopper door is hydraulically opened and closed with lever.

**Ignition** – turn key to right to start unit. Remove key when unit is not in use. Never leave machine unattended with key in ignition.

**Engine Preheat** – use the pre-heat position on the ignition switch when starting a cold engine. Hold the ignition key in that position until the glow lamp turns off. Preheating may not be needed if the engine is already warm.

**Transport Speed HI/LO** – ALWAYS SWEEP WITH TRANSMISSION IN LOW. Use high range when traveling between operations.

**Park Brake ON/OFF** – set park brake when unit is not in use or is parked on an incline. Make sure park brake is disengaged before operation.

**Throttle Control** – adjust engine speed with throttle. Start at low throttle, allow engine to warm up, then operate machine at full throttle.

**Machine Display** – This display has indicator lights for the following: Low Engine Oil, Glow Lamp, Neutral, Parking Brake, Low Battery, Low Hydraulic Oil and Hydraulic Temp. The display also has gauges for Fuel Level, Engine Temperature and Battery Level.



## **SAFETY WARNING!**

**Do not leave the Harper Hawk unattended, or attempt any service or inspection unless the machine has come to a complete stop and the engine has been shut off.**

### **Machine Display Identification**



**1. High Engine Temperature** – illuminates when the engine temperature exceeds 221° F (105° C). If this indicator is illuminated, STOP operation immediately and turn machine OFF. Inspect the radiator screen and radiator for debris. If debris is found, remove debris and restart machine to allow the engine to cool properly. Do NOT operate machine until the temperature returns to normal operating temperature. If illuminates repeatedly, further technical troubleshooting is necessary.

**2. Oil Pressure Indicator** – illuminates when oil pressure is below 7 psi (48 kPa). Turn the machine OFF immediately if this indicator is illuminated.

**3. Glow Plug Indicator** – illuminates when the ignition switch is in the pre-heat position and the glow plugs are activated. The pre-heat electrical circuit includes a glow lamp timer that controls the indicator. Once the indicator turns off, the machine is ready to start.

**4. Neutral Indicator** – illuminates when the machine is in neutral.

**5. Park Brake Indicator** – illuminates when the park brake is applied.

**6. Battery Indicator** – illuminates when the battery has low voltage.

**7. Low Hydraulic Oil Indicator** – illuminates when hydraulic oil is low in the hydraulic tank. An alarm also sounds when the hydraulic oil is low. Turn the machine OFF immediately if this indicator is illuminated and alarm sounds. Ensure that there are no leaks and fill hydraulic tank with hydraulic oil before restarting machine.

**8. High Temperature Hydraulic Oil Indicator** – illuminates when the hydraulic oil temperature exceeds 190° F. If this light illuminates, STOP operation of machine and turn machine OFF. Clean debris from radiator/oil cooler and screen. Then restart machine to allow the hydraulic oil to cool properly. If this light illuminates repeatedly, further technical troubleshooting is necessary.


**9. Fuel Gauge** – displays fuel level in fuel tank.

**10. Engine Temperature Gauge** – displays engine coolant temperature.

**11. Machine Hours** – Records and displays machine hours.

**12. Battery Gauge** – displays level of battery voltage.

## Deck Identification



**1. Anti-Scalp Wheels** – prevent the deck from gouging the turf when used in uneven terrain. These are intended as anti-scalp wheels only and not intended to roll on the ground continuously. See operation section in manual for adjustment instructions.

**2. Hydraulic Motor** – powers the sweeping rotor and paddle.

**3. Chain Drive** – connects sprockets of hydraulic motor, paddle, and sweeping rotor.


**4. Lower Deck Skirting** – seals the deck off at the ground level to reduce dust and contain debris inside the deck.

**5. Upper Deck Seal** – creates a seal between the deck and the deck transition.

**6. Adjustable Gauge Wheels** – controls the sweeping height of the deck and sweeping rotor. See Operation section in manual for adjustment instructions.

**7. Deck Lift Safety Lock** – used to secure the deck in the UP position. Safety lock is located on the front RH side of the deck. See instructions in the safety lock section.

## Hopper Identification



**1. Hopper Lift Cylinders** – used to raise and lower the hopper.

**2. Hopper Lift Safety Locks** – used to secure the hopper in UP position. Safety locks are located on both lift cylinders and should be used anytime a person is below the hopper. See instructions in the safety locks section.

**3. Pilot Operated Check Valves** – included in both the hopper lift and hopper door hydraulic plumbing circuit. See the hydraulic schematic in the parts manual for further details.

**4. Hopper Door Cylinders** – used to open and close the hopper door.

**5. Hopper Door Safety Lock** – use safety lock to secure hopper door in the OPEN position. Safety lock should be used when working inside hopper or below the open door. See instructions on next page.

**6. Sight Glass Windows** – located on each side of the hopper allows the operator to know the hopper fill level.

**7. Large Debris Door** – located on LH side of machine can be used to place larger debris (that can not be picked up by the machine) inside the hopper.

# Safety Guidelines

## Equipment & Controls

- **Read and understand this manual.**
- Altering this equipment in any manner which adversely affects its operation, performance, durability, or use will void the warranty and may cause hazardous conditions.
- Know the location and function of all controls and how to stop this equipment quickly in an emergency before you operate the equipment.
- Keep all nuts, bolts and screws tight to help ensure safe operation of this equipment.
- Use genuine factory parts or parts with equivalent characteristics, including type, strength and material. Failure to do so may result in product malfunction and possible injury to the operator and/or others.
- If hardware is not secure, or if some of the hardware is over-tightened, equipment failure may result, posing possible safety hazards.
- To prevent possible eye injury, always wear SAFETY GLASSES while operating equipment.
- To prevent hearing loss, always wear hearing protection while operating equipment.
- Do not allow children to operate or ride on this machine.

## Safety Decals

- All safety decals comply to the ISO Standard 11684: 1995(E).
- If safety related or instructional decals become illegible or are removed, replace them immediately. Decal locations and part numbers are identified in the parts manual and can be obtained from your local Harper Dealer.

- If you replace parts that have such decals attached to them, make sure the decals are replaced with current versions, and are on the replacement parts before the machine is operated again.

## Diesel Fuel

- Always use an approved container for transporting diesel fuel.
- Do not allow open flames or sparks while performing maintenance or refueling.
- Never remove fuel tank cap or add fuel when engine is running or while it is hot.
- Only use ultra low sulfur diesel.
- Never fill fuel tank indoors. Fumes are heavy and will sink to the lowest point, collect and become hazardous.
- Wipe up spilled fuel immediately.
- Do not store fuel in a room with an appliance that has a gas pilot or electrical switch that may cause sparks.
- Always store diesel outside in a safety can (a can with flame arrestor and pressure relief valve in pour spout).
- Never store the equipment with fuel in the tank inside a building where fumes may reach an open flame or spark.
- Allow the engine to cool before storing in any enclosure.
- Be certain to provide adequate ventilation if an engine must be run indoors - exhaust fumes are dangerous.



## **SAFETY WARNING!**



**Diesel fuel is extremely flammable and can be highly explosive.**

## Guards & Shields

- Keep all safety devices in place.
- Replace all worn, damaged, unusable, missing or lost safety shields and guards before operating the equipment.
- Keep the equipment in good operating condition.

## Battery



### **SAFETY WARNING!**

**Batteries can produce explosive gas. Use extreme caution when working on the battery.**

- Ventilate when charging battery or using in an enclosed space.
- DO NOT produce sparks from cable clamps, tools, or other sources; and DO NOT allow flames or smoking in the vicinity of the battery.
- Shield eyes when working near battery.

## Hydraulics



### **SAFETY WARNING!**

**Escaping fluid under pressure can penetrate skin causing serious injury. To prevent serious injury or death:**


- Relieve pressure on system before repairing, adjusting or disconnecting.
- Wear proper hand and eye protection when searching for leaks.
- Use wood or cardboard instead of hands when looking for leaks.
- Keep all components in good repair.
- Do not use any type of heat (welding, soldering, cutting torch, etc) near pressurized lines.

## Safety Interlocks/Wiring Logic

- To start the machine, it must be in neutral, and the deck rotor and paddle must be OFF.

- To turn the deck rotor and paddle ON, the operator must be in the seat, the hydraulic oil temperature must be below 190° F, and hydraulic oil must be present in the tank.
- There is a 2 second time delay added to the seat switch to account for bounce.
- The park brake is applied when the operator is out of the seat.

## Safety Symbols



1. High pressure fluid could be injected into body.




2. High pressure spray could erode flesh.



3. Hot surface could burn fingers or hands.



4. Never tip machine on soft ground or on a slope.




5. Stay a safe distance from machine when in use.




6. Stay clear of hopper door swing area while tractor engine is running.



7. Stay clear of raised hopper door unless safety locks are in place and secured.



8. Do not open or remove safety shields while engine/tractor is running.




9. Read manual before starting/operating machine.




10. Safety alert symbol.




11. Do not use hook for lifting machine.



12. Secure lifting cylinder with locking device before getting into hazardous area.



13. Crushing of toes or foot - Force applied from above.




14. Electrical shock/electrocution.

### Safety Decals

- If safety related or instructional decals become illegible or are removed, replace them immediately. New decals may be obtained from your local Harper Dealer.

- If you replace parts that have such decals attached to them, make sure the decals are replaced with current versions, and are on the replacement parts before the machine is operated again.

## Safety Symbol Locations





## Safety Locks



### **SAFETY WARNING!**

Failure to use safety locks could result in death or serious injury.



- **Deck Lift Safety Lock** – Secure the deck in the UP position when working or cleaning below the deck. The safety lock is located on the front RH side of the deck. Pin stop in the down position as shown in the picture below.



- **Hopper Lift Cylinders Safety Lock** – Secure the hopper in the UP position when working or standing below the hopper. Install cylinder safety lock to the hopper lift cylinders located on each side of the machine as shown in the picture below.



- **Hopper Door Safety Lock** – Secure hopper door in OPEN position when working inside the hopper or below the hopper door. Pin the safety stop to secure the door linkage as shown in the picture.



# Operation

## Before Operation

### Safety Checklist

- ☐ Read and understand the Operator's Manual.
- ☐ Ensure the machine is equipped with safety stops for the hopper lift cylinders and hopper door. Ensure that all shields and guards are in place.
- ☐ Check the seat belt to make sure that it functions properly.
- ☐ Know the location and function of all controls and how to stop quickly in an emergency. The machine controls are identified in the previous Controls Identification section.
- ☐ Replace damaged or missing safety decals.

### Perform the Daily Maintenance Checklist.

- ☐ Check engine oil level
- ☐ Check hydraulic oil level
- ☐ Check fuel level
- ☐ Check engine coolant level
- ☐ Visually inspect machine for fluid leaks, loose hardware, damaged parts, etc.
- ☐ Check radiator/oil cooler and screen for debris.
- ☐ Check engine air cleaner intake
- ☐ Grease as needed – see maintenance section for grease locations and intervals
- ☐ Visually inspect tires to ensure proper inflation

### Setting the Sweeping Height

- Park on level ground.
- Start the machine and raise the deck using the LH lever located on the console.
- Secure the deck using the deck lift safety locks.


- Adjust gauge wheel to desired height. The deck height is set from the factory in the middle hole of both the tube and the rod. At this setting, a new brush will contact the surface. To adjust the brush to be more aggressive, raise the gauge wheel to the next set of holes that line up. To be less aggressive, lower the gauge wheel to the next set of holes that line up. The adjustments are approximately  $\frac{1}{4}$ " (.64 cm) increments. Set the gauge wheel height the same on both sides.



- Check the sweeping height. Repeat the steps in this section until desired sweeping height is determined.



### Adjusting the Anti-Scalp Rollers

- The anti-scalp rollers are set from the factory so that the surface of the roller is approximately 1" (2.5 cm) below the front edge of the deck. To adjust, remove the bolts and nuts identified below and adjust up or down accordingly. The rollers can be adjusted in  $\frac{3}{8}$ " (.95 cm) increments. These are intended as anti-scalp rollers only and not intended to roll on the ground continuously.




#### Debris Door Inside of Hopper

- A debris fill door is located on the inside of the hopper. The door has two different settings: UP & DOWN. The debris fill door can affect how the hopper fills. When sweeping light, dry material place the fill door in the UP position. When sweeping heavier material, place the door in the DOWN position. If unsure, then place in the DOWN position



#### Operation

Adjust the seat and steering wheel as needed and wear seat belt during operation.



Wear approved eye and ear protection during operation.


#### Starting the Machine

- Use the preheat position of the ignition switch until the glow plug indicator on the machine display turns OFF. (Preheating is not necessary if the engine is already warm).
- Turn the machine to the right to start. *For the engine to start, it must be in neutral and the deck rotor/paddle must be OFF.*

#### During Operation

- In the event of an emergency, turn the key to the OFF position.
- Always keep a fire extinguisher near the Harper Hawk during operation.
- Keep clothing and all body parts away from rotating parts.
- Keep the engine area clean from debris and other accumulations to lessen the possibility of fire.

## Operating Machine



### Adjusting Engine Speed

- The engine rpm is controlled by the throttle control lever. Start at low throttle, allow engine to warm up, then operate at full throttle. When sweeping and transporting the machine, operate at full throttle. When raising and dumping the hopper, operate at low to mid throttle.


### Turning the Deck Rotor/Paddle ON/OFF.

- Using the paddle switch on the console, place the switch in the ON position. When switching ON, make sure the engine rpm is at low throttle. Once ON, speed the engine up to full throttle.
- To turn the deck ON, the operator must be in the seat.

### Raising and Lowering the Deck.


- Use the LH lever to operate the lift cylinder located on the rear side of the deck.
- The deck lift cylinder is attached to a pivot link that allows the deck to float with the contour of the ground. When the deck is lowered, hold the lever a few more seconds to ensure that the deck is in the float position.

- A deck height indicator is located on the front RH side of the deck so that the operator can easily view the deck height.



### Filling the Hopper

- The hopper debris level can be determined by looking through the sight glass windows located on each side of the hopper.
- The large debris door can also be opened to get a better view of the debris level inside the hopper. It can be used to place large debris, that cannot be picked up by the machine, inside the hopper.
- If the hopper is overfilled, it can cause the paddle rotor to plug.



### Emptying the Hopper

- When raising the hopper, only empty in an area with relatively flat ground. Do NOT raise the hopper on an incline greater than 10 degrees.
- Use the middle lever to operate the hopper lift cylinders.
- Once the hopper is in the UP position, use the RH lever to operate the hopper door cylinders to open and close the door.
- The hopper can be emptied in the low position; however, the angle of the hopper may not allow all the debris to slide out easily.

### High/Low Gear

- High or Low gear is selected using the paddle switch on the console.
- When transporting, use high gear which has a speed range of 0-10mph.
- When sweeping, use low gear which has a speed range of 0-5 mph.

### Applying the Park Brake

- When parking the machine or exiting the operator seat, apply the parking brake.
- The parking brake is applied using the paddle switch located on the console.
- The park brake is automatically applied when the operator is out of the seat.

### Machine Display

- While operating machine, pay attention to machine display to ensure proper temperature and fluid levels.

### Tipping Angle

- Never operate the machine on an incline greater than 20°.
- Never raise the hopper on an incline greater than 10°.

### Accessing Paddle

- If the paddle becomes plugged or needs cleaned, see instructions in Maintenance section to access paddle.

### **Sweeping Performance**

The Harper Hawk HK4400 has superior performance when sweeping and collecting the following items at the listed saturation levels.

| Material                                         | Saturation Level |
|--------------------------------------------------|------------------|
| Grass Clippings                                  | 50%              |
| Aeration Cores<br>up to ½" (1.27 cm)<br>diameter | 50%              |
| Leaves                                           | 100%             |
| Pine Needles                                     | 100%             |
| Pine Cones                                       | 100%             |
| Verticut Thatch                                  | 50%              |
| Twigs ½" (1.27 cm)<br>x 18" (45.72 cm)           | 100%             |

*For reference, the saturation levels are defined as the following: 100% - material is water logged and will not soak up any more moisture; 75% - Material feels wet still, no water running out of it; 50% - material has noticeably dried since operation was complete.*

### **After Operation**

Allow engine to run at low engine speed to properly cool before turning machine OFF.

Make sure engine, deck and hopper areas are clear of all debris.

### **Storage**

Ensure that the deck, hopper, and door are in the down or closed position. Make sure that the machine has properly cooled and is NOT a potential fire hazard.

# Maintenance

## Hydraulic System

- The hydraulic system of the HK 4400 is filled at the factory with Crown AW 46 hydraulic oil that has an ISO of 46.
- The HK 4400 has a 3 micron, beta rated hydraulic oil filter designed for long life.
- Hydraulic reservoir capacity - 2 gal (7.6 L).

The following list of hydraulic fluids are compatible and can be mixed with Crown hydraulic fluid. MIXING OTHER OILS THAT ARE **NOT INCLUDED ON THIS LIST COULD CAUSE GELLING AND DAMAGE TO THE HYDRAULIC COMPONENTS.** If another type of oil is desired, then the system must be completely drained and flushed first.

### **Appropriate replacements:**

**ISO 46:** Recommend for running in ambient air temperatures of 32°F-110°F, and it contains a kinematic viscosity rating around 46 cSt at 40°C. (1cSt = 1mm<sup>2</sup>/s)

- Mobil DTE 25
- Mobil DTE 15M
- Amoco Rykon Premium Oil ISO 46
- Chevron Rykon Premium Oil ISO 46
- Conoco Hydroclear AW MV 46
- Exxon Unavis N 46
- Pennzoil AWX MV 46
- Shell Tellus 52 M46
- Shell Tellus 52 V46
- Texaco Rando HDZ 46

- Monitor the needle in the filter indicator when the oil is at normal operating temperature every 100 hours.




- The filter (part no. 822044) does not need replaced until the needle is in the red portion of the gauge.
- To replace filter, twist the filter counter-clockwise. Replace with new filter by turning it clockwise until tight.



- The hydraulic oil level should be monitored daily with the hydraulic tank's sight glass on the right hand side of the hydraulic tank.
- Keep the hydraulic oil near the top of the sight glass at all times.
- Fill reservoir through the fill location on top of the reservoir.


## Grease Zerk Locations



## **PROCEDURE**

- 1) Park on level ground and set park brake.
- 2) Turn machine OFF.
- 3) Apply 4-5 pumps of grease to each zerk at the noted intervals listed above.

To access steering cylinder, pivot the seat forward by releasing the spring pins located at the rear of the seat as shown in the pictures below.




## Air Cleaner



- Make sure intake is always free of debris.
- When engine is turned off, remove the wing bolt.
- Replace the air filter according to the Maintenance Schedule.

## Cooling System



- The radiator and hydraulic oil cooler are located side by side in the same aluminum heat exchanger.
- Clear hydraulic oil cooler and radiator of debris with pressurized air daily or as needed.
- Check radiator level daily and only when engine is cool and not running.
- Remove cap (radiator fill) slowly to relieve any pressure that may be built up.
- Fill up radiator with coolant (50% water/ 50% antifreeze) until coolant is visible in neck of radiator.
- Coolant capacity - 2.25 gal (8.5 L).
- Make sure that the coolant recovery bottle has at least 1" of coolant in bottom. The presence of coolant in the recovery bottle does not mean radiator is full.
- Do NOT operate the machine if the engine temperature exceeds 230°F (110°C). Severe engine damage may occur if the machine is continuously operated above 221°F (105°C). If overheating does occur, diagnose the cooling system and ensuring proper coolant levels and proper air flow across the radiator. The high engine temperature indicator illuminates when the coolant reaches 221°F (105°C).



### **SAFETY WARNING**




Hot Coolant and steam from the radiator can cause severe burns. Never open the radiator cap of a hot engine.

## Engine Compartment

To access the engine, open the shields located above the engine by turning the latches counterclockwise.



## Engine Oil



- The dipstick and engine oil fill are located on the left hand side of the engine compartment.
- The engine oil filter is located on the rear lower side of the engine and it is accessible from the left hand side of the machine.
- To access engine oil fill or dipstick, open the LH shield by turning the latch counter-clockwise

## **PROCEDURE**

- Check engine oil level only when engine is off.
- Keep engine oil level between the FULL and ADD marks on dipstick at all times. DO NOT OVER-FILL.



## SAFETY WARNING




Keep dipstick and oil fill cap secured tightly. Engine oil may escape through these orifices when engine is running causing severe burns.


|                               |                                 |
|-------------------------------|---------------------------------|
| above 25°C (77°F)             | SAE30 or SAE10W-30<br>SAE15W-40 |
| -10°C - 25°C<br>(14°F - 77°F) | SAE10W-30<br>SAE15W-40          |
| below -10°C (14°F)            | SAE10W-30                       |

- Filled with SAE10W-30 from the factory, 6.0 L capacity, and change after the first 50 hours. Then change engine oil every 200 hrs.


### Fuel Components



- Fuel Filter (302057) is located on the left hand side of the machine beside the radiator.
- The fuel pump, in-line fuel filter, and fuel shutoff are located below the fuel tank. These components can be accessed through the frame cutouts between the two rear tires.



### Fuse/Relay Panel




- Located under operators' console, through the access door.
- Refer to the parts section for electrical schematic and other electrical components.

### Deck Maintenance/Service


#### Liner Inspection

- The deck assembly and deck transition assembly both include bolt-on replaceable steel wear liners.
- To access liners for inspection, raise the hopper and install safety locks on both lift cylinders.
- Inspect wear liners every 250 hours. Replace liners before it wears through. The part number for the two deck liners is 317311. When operating in sandy conditions, inspect every 100 hours.




## Paddle

- Accessing paddle – raise the hopper and install safety locks on both lift cylinders. Remove the front two pins on the chute assembly and release the two spring pins located on the paddle shield. Then flip these two components towards the rear to gain access to the paddle rotor.



- Inspecting paddle blades – inspect all four paddle blades for significant damage, such as being bent or cracked. Check to make sure that the paddles are not rubbing on the deck housing by looking for excessive wear on the deck housing. Replace paddles as needed. The replacement paddle part number is 317180. See the parts manual for an exploded view.



- Inspect paddle bearings – inspect the paddle bearings, located on each end of the paddle rotor, for damaged seals or excessive movement of the shaft contained by the bearing.

**NOTE: The deck liner is easier to inspect and replace with the paddle shield and chute assembly folded backwards.**


- Re-install all shields and parts removed before operating machine.

## Brush


- The brush is approximately 12" in (30 cm) diameter when it is new. As it wears, the overall diameter will be reduced. Replace the brush when the overall diameter is less than 10" or the sweeping performance is reduced.

## Replacing brush


- Remove the shield located on the LH side of the deck to access the chain drive. Remove the rear two bolts and loosen the front two bolts.



- Loosen the chain by removing the two nuts that secure the idler spring. Then remove the chain from the sprockets.
- Remove bolt that secures the brush sprocket and then remove sprocket.
- Remove side skirts and retainers on each side.



- Remove bolts that attach bearings to the deck and lower brush assembly down from the deck. Replace brush halves.




- Re-install all parts that were removed. See next section for instructions on how to properly tighten the chain.

### Chain Drive


- Accessing chain drive - remove the shield located on the LH side of the deck to access the chain drive. Remove the rear two bolts and loosen the front two bolts.



- Tightening chain – position roller chain on sprockets as shown below. Tighten hex nut to compress the idler spring until the flat washer contacts the black nylon collar located on the inside of the idler spring. Tighten jam nut to lock in place.



- Chain – inspect the chain every 250 hours and replace the chain when chain elongation has reached 3%, chain has become damaged, or improper flex of chain is found.
- Checking for elongation – with the chain set at the proper tension, count 12 pins on the roller chain, and measure the center to center distance between the first and last pin. When new, this measurement is 5.50" (13.97 cm). When this measurement is greater than 5.66" (14.37 cm), the chain should be replaced.




- Sprockets – inspect the sprockets every 250 hours and replace the sprockets when the teeth become sharp and pointed. See parts manual for sprocket part numbers.

## Hopper Maintenance/Service


### Liner Inspection

- The hopper assembly includes a bolt-on replaceable UHMW plastic liner.
- To access the liner for inspection, open the hopper door and install the hopper door safety lock.
- Inspect wear liner every 250 hours. Replace liner before it wears through to the hopper sheet metal. The part number for the hopper liner is 302121. When operating in sandy conditions, inspect every 100 hours.



### Return Air Screens

- Inspect return air screens located inside the hopper to ensure that screens are clear of debris to allow proper return air flow. Clear debris as needed.



## Tow Procedure

To move the machine without the engine running, the park brake must be released, **and** the bypass valve must be opened on the propulsion pump.

### Park Brake Release

- Each wheel motor contains a park brake that is mechanically applied and hydraulically released. When the engine is OFF the park brakes are applied to all wheel motors.



### **PRECAUTION**





**Towing or pushing the unit with the park brakes applied may cause serious damage to internal brake parts.**

- The park brakes can be released by applying hydraulic pressure to each of the wheel motors brake release ports. To accomplish this, follow the steps below.

### **Procedure**

- Locate the brake release valve located behind the operator's seat and below the engine shields.






- Turn knob clockwise (CW) all the way to close needle valve. This will separate the brake release circuit from the rest of the hydraulic system.
- Using the hand pump, pressurize the brake release circuit to 350 psi. A pressure gauge is mounted to the valve block to display the brake release system pressure.
- When moving machine, keep an eye on the pressure gauge to ensure that the pressure remains above 250 psi.
- After moving is complete, turn the knob on the needle valve counter-clockwise (CCW) all the way to relieve the pressure.

### **Opening the By-Pass Valve**

- The by-pass valve is located on the bottom side of the propulsion pump that is directly coupled to the engine. The valve can be accessed below the engine compartment.
- The by-pass connects the ports A-B and must be used only in case of emergency and only for moving machine short distances.

**! PRECAUTION !**  
By-pass valve is intended for moving a machine for very short distances at very slow speeds. It is not intended as a tow valve.

- To open, turn by-pass valve counter-clockwise (CCW) two full turns using a 17 mm wrench.



**! PRECAUTION !**  
To avoid leakage, do not exceed two CCW turns of the screw.

- After moving machine is complete, close the by-pass by turning valve CW.

## Tie Down Locations for Transport



- Use at least 5/16" Grade 70 Transport Chain or equivalent strength while transporting.
- Tie downs should be secured as shown when transporting.
- All 4 of the tie down locations are identified with this decal. One on each side and 2 on the rear of the machine.
- When transporting on a truck or trailer, ensure that all moving parts are in the down or closed position.
- When transporting a machine with a canopy installed, load the machine with the hopper facing forward.




## Serial Number ID


- **Machine Serial Number** - Located on the LH side of the operator seat.



- **Engine Serial Numbers** - Engine model and serial number are stamped in the engine block on the starter side of the engine. Serial number decal is located on top of the engine.



- **Propulsion Pump Serial Numbers** - Located on front side of the propulsion pump.



- **Front Wheel Motor Serial Numbers** - Located on the front side of the wheel motor.
- **Rear Wheel Motor Serial Numbers** - Located on the bottom side of the wheel motor, and it can be viewed through the cutout on the frame.

Front



Rear



## Standard Torque Chart



### SAFETY WARNING!

Refer to the Standard Torque Chart whenever bolts, nuts or screws are tightened.

### PRECAUTIONS

- When tightening two or more fasteners on the same part, DO NOT tighten the fasteners completely one at a time. To avoid distortion, first tighten all fasteners in sequence to one-third of torque value, then tighten to two-thirds of torque value, then tighten to full value.
- All lugnuts should be torqued to 147 ft-lbs (199 N-m).

### U.S. BOLT TORQUE SPECIFICATIONS

Torque in foot-pounds

| Diameter | Thread per inch |     |       |       |      |
|----------|-----------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------|-------|------|
|          |                 | SAE 2                                                                                                                                                                                                                                                                                                                                   | SAE 5 | SAE 8 | SHCS |
| 1/4      | 20              | 4                                                                                                                                                                                                                                                                                                                                       | 8     | 12    | 14   |
| 1/4      | 28              | 6                                                                                                                                                                                                                                                                                                                                       | 10    | 14    | 16   |
| 5/16     | 18              | 9                                                                                                                                                                                                                                                                                                                                       | 17    | 25    | 29   |
| 5/16     | 24              | 12                                                                                                                                                                                                                                                                                                                                      | 19    | 29    | 33   |
| 3/8      | 16              | 16                                                                                                                                                                                                                                                                                                                                      | 30    | 45    | 49   |
| 3/8      | 24              | 22                                                                                                                                                                                                                                                                                                                                      | 35    | 50    | 54   |
| 7/16     | 14              | 24                                                                                                                                                                                                                                                                                                                                      | 50    | 70    | 76   |
| 7/16     | 20              | 34                                                                                                                                                                                                                                                                                                                                      | 55    | 80    | 85   |
| 1/2      | 13              | 38                                                                                                                                                                                                                                                                                                                                      | 75    | 110   | 113  |
| 1/2      | 20              | 52                                                                                                                                                                                                                                                                                                                                      | 90    | 120   | 126  |
| 9/16     | 12              | 52                                                                                                                                                                                                                                                                                                                                      | 110   | 150   | 163  |
| 9/16     | 18              | 71                                                                                                                                                                                                                                                                                                                                      | 120   | 170   | 181  |
| 5/8      | 11              | 98                                                                                                                                                                                                                                                                                                                                      | 150   | 220   | 230  |
| 5/8      | 18              | 115                                                                                                                                                                                                                                                                                                                                     | 180   | 240   | 255  |
| 3/4      | 10              | 157                                                                                                                                                                                                                                                                                                                                     | 260   | 380   | 400  |
| 3/4      | 16              | 180                                                                                                                                                                                                                                                                                                                                     | 300   | 420   | 440  |
| 7/8      | 9               | 210                                                                                                                                                                                                                                                                                                                                     | 430   | 600   | 640  |
| 7/8      | 14              | 230                                                                                                                                                                                                                                                                                                                                     | 470   | 660   | 700  |
| 1        | 8               | 320                                                                                                                                                                                                                                                                                                                                     | 640   | 900   | 980  |
| 1        | 12              | 350                                                                                                                                                                                                                                                                                                                                     | 710   | 990   | 1060 |

Baseline torque is calculated for a non-lubricated, un-plated bolt.

### BOLT TORQUE FACTORS

| LUBRICANT OR PLATING | TORQUE CHANGES           |
|----------------------|--------------------------|
| Oil                  | Reduce torque 15% to 25% |
| Chrome plating       | No change                |
| Cadmium plating      | Reduce torque 25%        |
| Zinc plating         | Reduce torque 15%        |

## Service Parts

| Filters                   | Part # |
|---------------------------|--------|
| Engine Air Filter         | 802064 |
| Engine Oil Filter         | 302058 |
| Fuel Filter (Cannister)   | 302057 |
| Fuel Filter (In-line)     | 822044 |
| Belts                     |        |
| Engine Fan Belt           | 802063 |
| Wheels and Tires          |        |
| Front Wheel               | 302125 |
| Front Tire                | 302127 |
| Front Wheel/Tire Assembly | 305083 |
| Rear Wheel                | 302126 |
| Rear Tire                 | 302128 |
| Rear Wheel/Tire Assembly  | 305084 |
| Replaceable Wear Items    |        |
| Deck & Transistion Liner  | 317311 |
| Paddle Blades             | 317180 |
| Replacement Brush         | 302003 |
| Hopper Liner              | 302121 |

*For all other service parts, use parts manual to identify part numbers.*

## **Maintenance Schedule**

### **Daily or Before Starting the Engine**

- Check Engine Oil Level..... SAE 10W30 or 15W40
  - (See Maintenance section for details)
- ☐ Check Hydraulic Oil Level..... Crown AW46
  - (See Maintenance section for details)
- ☐ Check Fuel Level..... Clean #2 Diesel Fuel
- ☐ Check Engine Coolant Level..... 50% anti-freeze, 50% water
- ☐ Visually Inspect..... Fan belt, bolts, fittings, hoses (fluid leaks, or any damaged parts)
- ☐ Check Radiator & Oil Cooler..... Clean off debris as needed
- ☐ Check Engine Screens..... Clear debris as needed to ensure proper air flow
- ☐ Check Air Cleaner Intake..... Clear debris as needed
- ☐ Grease..... As needed; see Maintenance section for locations and intervals
- ☐ Check Drive Tires..... Visually inspect tires to ensure proper inflation & no damage

### **Every 50 Hours**

- ☐ Change Engine Oil & Filter..... After initial 50 hours, change engine oil
  - (every 200, thereafter)
- ☐ Change Inline Fuel Filter..... After initial 50 hours, change filter
  - (P/N: 302103, every 200 thereafter)
- ☐ Check Tire Pressure..... Inflate all tires to 20 psi (138 kPa)
- ☐ Check of Fuel Pipes & Clamps..... See Kubota Manual for details
- ☐ Check Lug nuts..... Torque to 147 ft-lbs (199 Nm)

### **Every 100 Hours**

- ☐ Check Engine Air Filter..... Clean or replace as needed (P/N: 802064)
- ☐ Check Fan Belt Tightness..... Tighten as needed
- ☐ Check Hydraulic Oil Filter..... Replace when needed (P/N: 822044)

### **Every 200 Hours**

- ☐ Change Engine Oil..... SAE 10W30 or 15W40
  - (See engine manual)
- ☐ Change Engine Oil Filter..... P/N: 302058
- ☐ Check Intake Air Lines..... Clear debris as needed
- ☐ Replace In-line Fuel Filter..... P/N: 302103
- ☐ Check Radiator Hoses & Clamps..... Repair or replace as necessary

### **Every 250 Hours**

- ☐ Inspect deck transition wear liners..... Replace as needed (P/N: 317311)
- ☐ Inspect deck chain drive and sprockets..... Tighten chain as needed; Replace parts as needed
- ☐ Inspect brush..... Replace as needed (P/N: 302003)
- ☐ Inspect hopper liner..... Replace as needed (P/N: 302121)
- ☐ Inspect hopper return air screens..... Clear debris as needed.

### **Every Year**

- ☐ Replace Engine Air Filter..... P/N: 802064
- ☐ Check Hydraulic Oil Condition..... Crown AW46
  - (See Maintenance section for details)
- ☐ Check Battery..... Clean terminals if necessary

### **Every 500 Hours**

- ☐ Replace Engine Fan Belt..... P/N: 802063
- ☐ Replace Cannister Fuel Filter..... P/N: 302057

### **Every 1500 Hours**

- ☐ Check fuel injection nozzle injection pressure ...See Kubota Manual
- ☐ Change Hydraulic Oil..... Crown AW46
  - (See Maintenance section for details)

### **Every 3000 Hours**

- ☐ Check Fuel Injection Pump

### **Every Two Years**

- ☐ Change Engine Coolant..... 50% anti-freeze, 50% water
- ☐ Replace Battery..... P/N: 832011
- ☐ Replace radiator hoses and clamp bands..... See parts manual
- ☐ Replace fuel hoses and clamp bands..... See parts manual
- ☐ Replace air intake hose..... See parts manual

## NOTES

Harper Industries, Inc.  
151 E. Highway 160  
Harper, KS 67058

Telephone: 620-896-7381  
Toll-Free: 800-835-1042  
Fax: 620-896-7129

Website: [www.harperindustries.com](http://www.harperindustries.com)

E-mail: [info@harperindustries.com](mailto:info@harperindustries.com)